

BDSVA

Ellies Door and Window Vibration alarm

Product Overview

Ellies Door and Window Vibration alarm, Ideal for use on doors and Windows, Easy to Install, Battery operated, No wiring required, Suitable for Indoor use only, Required 3x LR44 batteries to operate



Specifications

Overview:

The Ellies Door and Window Vibration Alarm is a cost-effective and reliable security solution designed to protect your home or business from unauthorised entry. This compact alarm system is ideal for securing doors, windows, and even display or medicine cabinets. The alarm is triggered by vibrations caused by attempts to force entry, instantly sounding a loud 90 dB siren that can deter intruders and alert you or your neighbours. Easy to install with adhesive backing, this battery-operated device requires no wiring, making it a hassle-free addition to any security setup. Designed for indoor use, the Ellies Door and Window Vibration Alarm provides peace of mind by offering enhanced protection for vulnerable entry points with minimal effort. Ideal For Use In Homes, Offices, Garages, Sheds, Caravans, And Boats. Protect Your Home's Main Entry Points, Including Doors And Windows. Use On Display Or Medicine Cabinets To Prevent Unauthorised Access.

- Vibration-Activated Security: Alarm Sounds Instantly When Doors Or Windows Experience A Forceful Vibration
- Provides A Strong Deterrent To Potential Intruders.
- Loud 90 Db Alarm: Emits A Powerful Siren That Can Scare Off Burglars And Alert Nearby Occupants.
- The Device Attaches Easily To Any Clean, Flat Surface Using Adhesive Tape-No Tools Or Wiring Required.

ComX Computers

Product Specification Sheet

- Suitable For Doors, Windows, Display Cabinets, And Medicine Cabinets, Making It A Flexible Security Option.
- Battery Operated: Powered By 3x LR44 Batteries, .
- Compact Design: Slim And Discreet, The Alarm Blends Seamlessly Into Your Home Or Business Environment.
- Automatic Reset: The Alarm Sounds For 25 Seconds And Then Automatically Resets, Avoiding Unnecessary Noise While Maintaining Security.

Usage Instructions

- Installation: Peel Off The Protective Paper On The Adhesive Backing And Attach The Alarm To A Clean, Flat Surface On Your Door Or Window.
- Activation: Switch The Alarm To The "On" Position. The Device Will Emit Three Short Beeps To Indicate It Is Armed.
- Operation: If A Vibration Or Shock Is Detected, The Alarm Will Sound A 90 Db Siren For 25 Seconds, Then Automatically Reset.
- Deactivation: To Disarm The Alarm, Switch It To The "Off" Position.
- Battery Replacement: Powered By Three LR44 Batteries.
- Replace The Batteries Annually Or When The Alarm Becomes Less Effective.

Specifications:

© 2024 Respective owners and brand holders. This table has been carefully researched and generated by ComXpert International CC (<http://www.comx.co.za>), however, errors and omissions may occur. Only references to South Africa apply. All products are sourced in South Africa from the official suppliers and the warranty is that of the local supplier. E&OE. This table and our site's content may be used on condition that this notice and link remains intact and unaltered.

Specifications

Product Code	BDSVA
Stock Code	BDSVA
Description	Ellies Door and Window Vibration Alarm
Product Type	Battery Operated Door and Window Vibration Alarm
Components	Alarm Main Unit
Current When Disarmed	
Current When Armed	
Alarm Volume	90dB +/- 2dB At Distance 0.3m
Alarm	Sound 25 +/- 2 seconds
Power Source	3x LR44 Batteries (Required, Pre-installed)
Colour	White
Usage	Suitable for Indoor Use Only
Installation	Adhesive Mounting, No Wiring Required
Dimensions	9.5 cm (H) x 4.5 cm (W) x 1 cm (D)

Usage Instructions

Installation	Peel Off The Protective Paper On The Adhesive Backing And Attach The Alarm To A Clean, Flat Surface On Your Door Or Window.
Activation	Switch The Alarm To The "On" Position. The Device Will Emit Three Short Beeps To Indicate It Is Armed.
Operation	If A Vibration Or Shock Is Detected, The Alarm Will Sound A 90 Db Siren For 25 Seconds, Then Automatically Reset.

ComX Computers

Product Specification Sheet

Deactivation	To Disarm The Alarm, Switch It To The "Off" Position.
Battery Replacement	Powered By Three LR44 Batteries.
	Replace The Batteries Annually Or When The Alarm Becomes Less Effective.

Product Information Online

For the latest product information, availability and purchasing details, please visit the product page:

Product page: <https://www.comx.co.za/BDSVA-Ellies-Door-and-Window-Vibration-alarm-Buy-p-308836.php>

Images and specifications are provided for reference and are subject to change without notice. E&OE.

Terms of Use: <https://www.comx.co.za/terms-of-use.php>

Terms of Sale: <https://www.comx.co.za/terms-of-sale.php>

PDF generated: 2026-10-07 19:40:15.

This PDF was generated automatically and may include content prepared or assisted by automated or AI-based systems. While reasonable care is taken to ensure accuracy, errors or omissions may occur.

For the most current and accurate product information, please refer to the product information available on our website. If any specification or other information differs from information published elsewhere, please confirm the details with us before relying on the information or making a purchasing decision.

If you identify an error or discrepancy, please report it to us so that we may investigate and correct it where necessary.